



## PREPARING THE TREATMENT


### 1 Job selection

From the Spraying Menu, press key and hold to select spraying job.




### 2 Reset total counters

From the Spraying Menu, press key and hold to select spraying job.




### 3 Tank Filling

From the Spraying Menu, press to select the value to be set.




## USE


### 1 Automatic treatment control




- 1 Press to enable automatic mode.
- 2 Turn on the section valves required.
- 3 Drive to the start of the field.
- 4 Set the main control switch up.
- 5 Run the treatment.




### 2 Temporary variation in rate



- 1 Press the switch up to increase the delivery value.
- 2 Press the switch down to decrease the delivery value.
- 3 Press to reset the rate variation percentage.




## KEY TO ITEMS ON DISPLAY




## OPERATING ALARMS


- The computer is not receiving the speed of the tractor and spraying is enabled (main control switch "ON"). The messages shown flash alternating.



- The computer detects zero flowrate and spraying is active (main switch valve "ON"). The messages shown flash alternating.



- Speed too high or low for the set dosage.



## SELECTING THE WHEEL TYPE (CONSTANT)

From the Spraying Menu, hold down to access the User Menu.

