

Fitting dual sided conveyor on SIT-FS300C or 500C:



Left – back shot of 2 halves of conveyor bolted together

Right – front shot of 2 halves of conveyor bolted together

Below left – Front right hand bracket with conveyor bolted correctly

Below right – Front Left hand bracket with conveyor bolted correctly



Above – bottom rear support bracket bolted in place



This item no longer required on front of spreader (keep in case it's needed in future)