



NOTES:

1. DUMP VALVE WIRES MAY NEED TO BE REVERSED AT VALVE DIN CONNECTOR ON MT90LOOM/1 TO CONFIRM CORRECT VALVE OPERATION
2. SERVO VALVE WIRES MAY NEED TO BE REVERSED AT VALVE DIN CONNECTOR ON MT90LOOM/1 TO CONFIRM CORRECT VALVE OPERATION

MT90LOOM/110
 AUTO SECTION CONTROL
 ADAPTOR LOOM

4th MARCH 2010