



NOTES:

- SERVO VALVE WIRES MAY NEED TO BE REVERSED AT PINS 1 & 3 IN 24 PIN CONNECTOR ON MT90LOOM/2-RV50 TO CONFIRM CORRECT SERVO VALVE OPERATION

MT90LOOM/2-RV50
 RAVEN PRODUCT CONTROL NODE
 ADAPTOR LOOM

2nd AUGUST 2011

