

QM-420 BOOM ARM OPTIONS

Used with Standard and Wide Tower / Standard and Wide Terracing Tower options.

Left-hand = 2J, 2F, 2G and Right-hand = 3J, 3F & 3G. Images below are LH version, not to exact scale.

NOTE


Drawings are for illustration purposes only - refer to sprayer for actual plumbing. Parts lists are indicative of the sprayer type.

Items in italics or without a part number are non stocked items and may need to be specially ordered.

For further parts information refer to www.croplands.com.au


HP-274A-2J / 3J

For Narrow Row



HP-274A-2F / 3F

Up to 3.0 / 3.2 m Row



HP-274A-2G / 3G

For Wide Row

