


NOTE:

DUMP A & DUMP B WIRES MAY NEED TO BE REVERSED FOR CORRECT DUMP VALVE OPERATION



MT90LOOM/1C4TGS2
4 SECTION + FLOW POWER
SPRAYER VALVE LOOM