FL2130 Series



FL2130-132

Spare Part Description	Position	Part Number
Pressure Switch	16	FL02095-115
Diaphragms	11	FL21010-103
Check Valves	12	FL20028-053
Lower Housing	13	FL20316-003

FL2130-232

Spare Part Description	Position	Part Number
Pressure Switch	16	FL02095-115
Diaphragms	11	FL21010-103
Check Valves	12	FL20028-053
Lower Housing	13	FL20316-003